


VeriFone Paper Load Instruction Sheet




- 1 If the green LED is blinking the terminal needs paper, press the button on the side of the terminal to unlatch the paper roll cover.
- 2 Remove the empty roll.
- 3 Position the roll inside of the paper tray so that the paper feeds from the bottom of the roll.
- 4 Unroll the paper past the metal strip and cut off the glued end.
- 5 Close the cover by gently pressing directly on the paper roll cover until it clicks shut and tear off the excess paper.



Nurit 2085 Paper Load Instruction Sheet




- 1 Remove the printer compartment cover (lift from back) and remove the empty roll.
 - 2 Press and hold <Feed> to remove the remaining paper. *
 - 3 Position the roll inside of the paper tray so that the paper feeds from the bottom of the roll.
 - 4 Insert the leading edge of the paper at the bottom of the feed roller and press and hold <Feed> until it is fed past the roller and exits approximately 2 inches past the metal strip.
 - 5 Slide the printer compartment cover in place (front cover first) while lightly pressing at the rear until it snaps in place and tear off the excess paper.
- * Do not pull the paper backwards through the printer mechanism, this could damage the printer.



VeriFone Paper Load Instruction Sheet




- 1 If the green LED is blinking the terminal needs paper, press the button on the side of the terminal to unlatch the paper roll cover.
- 2 Remove the empty roll.
- 3 Position the roll inside of the paper tray so that the paper feeds from the bottom of the roll.
- 4 Unroll the paper past the metal strip and cut off the glued end.
- 5 Close the cover by gently pressing directly on the paper roll cover until it clicks shut and tear off the excess paper.



Nurit 2085 Paper Load Instruction Sheet



- 1 Remove the printer compartment cover (lift from back) and remove the empty roll.
 - 2 Press and hold <Feed> to remove the remaining paper. *
 - 3 Position the roll inside of the paper tray so that the paper feeds from the bottom of the roll.
 - 4 Insert the leading edge of the paper at the bottom of the feed roller and press and hold <Feed> until it is fed past the roller and exits approximately 2 inches past the metal strip.
 - 5 Slide the printer compartment cover in place (front cover first) while lightly pressing at the rear until it snaps in place and tear off the excess paper.
- * Do not pull the paper backwards through the printer mechanism, this could damage the printer.





To help us better serve you, please call to place your paper re-order when you're down to your last 2 rolls or at least 48 hours in advance to ensure a timely delivery and avoid running out.

Thank You



To help us better serve you, please call to place your paper re-order when you're down to your last 2 rolls or at least 48 hours in advance to ensure a timely delivery and avoid running out.

Thank You



To help us better serve you, please call to place your paper re-order when you're down to your last 2 rolls or at least 48 hours in advance to ensure a timely delivery and avoid running out.

Thank You



To help us better serve you, please call to place your paper re-order when you're down to your last 2 rolls or at least 48 hours in advance to ensure a timely delivery and avoid running out.

Thank You